
### **C-VAV** self-sufficient & connected



- to manage the airflow of fresh air in offices, commercial buildings and classrooms.
- to regulate the airflow and measure the indoor air quality with its integrated sensors (humidity, temperature and CO<sub>2</sub>).

The airflow can also be regulated by an external 0-10 V signal or a dry contact from a remote sensor (presence or CO<sub>2</sub> sensor).

**e-VAV** is energy self-sufficient and doesn't require any power wiring. It generates its own electricity thanks to its turbine operating by the air flow and its energy harvesting system. This energy is used to supply electricity to the damper and measure indoor air quality.



#### **VERSIONS**

- e-VAV, variable air volume damper, energy self-sufficient
- e-VAV QAI, variable air volume damper with air quality sensor (CO<sub>2</sub>), energy self-sufficient
- e-SENSE, air quality sensor (CO<sub>2</sub>, HR, T°), energy self-sufficient
- Pack e-VAV QAI: made of one e-VAV QAI with CO<sub>2</sub> sensor for extract, one e-VAV for supply, and one specific
  master/slave wire

#### CONSTRUCTION

	e-VAV					
	Ø125 mm					
Casing	PC-ABS, c	ertified M1	PC-ABS M0 in option			
Iris damper	PC-ABS, certified M1					
Airproofing membrane	Seal					
Connection	Male connection with EPDM seal					

#### **TECHNICAL SPECIFICATIONS**

	e-VAV
Casing airtightness	Class C
Upstream/downstream airtightness	Not classified
Operating temperature	+0°C to +45°C
Operating relative humidity	080 % RH (non-condensing)
Wire control (room sensors)	010 V signal or ON/OFF switch
Communication	LoRaWan








## **C-VAV** self-sufficient & connected

#### **DIMENSIONS**



	Ø125 mm	Ø160 mm	Ø200 mm	Ø250 mm
Length in mm	105	105	200	200
Height H1 in mm	130	156	173	198
Height H2 in mm	172	190	248	298
Weight in kg	0.45	0.70	2	4

#### **AIR MANAGEMENT SPECIFICATION**

	e-VAV				
	Ø125 mm   Ø160 mm   Ø200 mm   Ø250 mn				
Airflow range min	30 m³/h 40 m³/h 60 m³/h 90 m				
Airflow range max	220 m³/h 400 m³/h 600 m³/h 1100 m³				
Pressure range min - max	10 Pa - 250 Pa				

The advised airflow range is from 0.5 m/s to 5 m/s

#### **ACOUSTIC PERFORMANCES** WITH A 50 Pa PRESSURE LOSS

	Air	Airflow	63 Hz	125 Hz	250 Hz	500 Hz	1000 Hz	2000 Hz	4000 Hz	8000 Hz	Clobal
	velocity m/s	m <sup>3</sup> /h	Air-regenerated, sound power level Lw			Global Lw (dBA)					
	0.5	22	53	47	44	37	27	19	19	21	39
	1	44	55	64	54	39	37	23	20	21	50
Ø125 mm	2	88	53	56	51	43	42	32	26	21	47
Ø125 IIIII	3	133	54	52	56	47	45	37	32	22	50
	4	177	55	54	57	51	49	45	37	24	54
	5	221	56	54	52	53	53	50	42	27	56
	0.5	36	55	40	34	26	21	16	17	31	33
	1	72	64	55	47	41	37	34	31	32	38
Ø160 mm	2	144	62	57	57	50	41	37	33	33	46
וווווו טסוש	3	217	57	55	59	42	38	31	24	32	49
	4	289	58	57	54	46	42	36	30	30	49
	5	361	57	57	62	49	45	46	35	32	56

Data for Ø200 and Ø250 on request







## **C**··**VAV** self-sufficient & connected


#### TECHNICAL SPECIFICATIONS SENSORS AND COMMUNICATION

	RH operating range	0 to 80 % (non-condensing)	
Relative Humidity	Accuracy	± 3 %	
and Temperature	Operating temperature T°	0 to 45 °C	
sensor	Accuracy	± 1°C	
	Туре	Low power MEMS sensor	

CO <sub>2</sub> sensor	CO <sub>2</sub> operating range	0 to 2000 ppm
	Accuracy	± 50 ppm
	Туре	NDIR low power


Communication	Protocol	LoRaWan	
RF	Frequency band	868 GHz	

#### **DESCRIPTION**



#### The external box has 1 plug:

- One RJ12 to connect a CO<sub>2</sub> sensor or a presence detector





FT\_e:WAV\_05/2023\_EN Information and data can not be considered as contractual. Design and data changes may occur without notice during F2A's continuous product development.






### **C**·VAV self-sufficient & connected

#### **OPERATING PRINCIPLE**


Supply or exhaust air controlled by a room CO<sub>2</sub> sensor with an e-VAV-S (S=Standard)



The damper is controlled by a  $0..10\,\mathrm{V}$  signal from a room  $\mathrm{CO}_2$  sensor which itself measures in real time the  $\mathrm{CO}_2$  concentration and sends a  $0..10\,\mathrm{V}$  signal to the damper to adapt the airflow rate.

The damper is factory set. The remote sensor can be supplied with 24 V by an external source.

The CO<sub>2</sub> sensor can be replaced by a presence detector.






FT\_e-VAV\_01/2024\_EN. Information and data can not be considered as contractual. Design and data changes may occur without notice during F2A's continuous product development.





## C·VAV self-sufficient & connected

#### Wiring diagram



#### Equipment list:

- 1 e-VAV
- 1 CO<sub>2</sub> room sensor 24 V
- 1 power transformer 230 V-24 V
- In option: presence detector.

#### Exhaust air controlled by an e-VAV QAI with integrated CO<sub>2</sub> sensor




#### Equipment list:

• 1 e-VAV QAI

The **e-VAV QAI** damper in the exhaust is controlled by the CO<sub>2</sub> measured by its integrated sensor.

The damper is factory set with minimum and maximum airflow and  ${\rm CO_2}$  values.

#### No connection needed



 $CO_2$  min: 500 ppm  $\rightarrow$  airflow min  $CO_2$  max: 1500 ppm  $\rightarrow$  airflow max








## C·VAV self-sufficient & connected

Exhaust air controlled by an e-VAV QAI with integrated CO<sub>2</sub> sensor at the exhaust and one slave e-VAV at the supply




The **e-VAV QAI** damper in the exhaust is controlled by the  $CO_2$  measured from its integrated sensor. It is factory set with minimum and maximum airflow and  $CO_2$  values.

The **e-VAV** damper at the supply is on slave mode controlled by the **e-VAV QAI** master. The signal is transmitted via a specific wire provided.

Pack e-VAV QAI equipment list:

- 1 e-VAV QAI at the exhaust
- 1 e-VAV at the supply
- 1 master/slave wire









### **C**·VAV self-sufficient & connected

#### Wiring diagram



1/ Select the RJ45 connection
On the lateral side of the electrical box



3/ Check the cable is well connected then do the same with the other e-VAV



2/ Plug the cable delivred with the e-VAV



**4/** The 2 e·VAV are now connected in master/slave mode

#### INSTALLATION

Always install the **e-VAV** with the airflow facing the turbine.

The damper fits between two sections of ductwork thanks to EPDM seals. No screw is needed.







#### **COMMISSIONING**

The **e-VAV** needs an air flow to be activated. Start the AHU and wait for the **e-VAV** to start the regulation. The start-up time is a maximum of 60 minutes and an average of 40 minutes.

After 60 min, the  $e ext{-VAV}$  starts to reach the target according to the signal it receives: dry contact, 0-10V or  $CO_2$ . LoRa commissioning: all products are labelled with their LoRa identifier

N° Article: EVAVD125-S **Designation:** EVAV D125 HRT

Dev EUI: XX-XX-XX-XX-XX-XX-XX

Label: eVAV T5 Building: n°1 Place: R5

Regulation: 0-10 V

Airflow min: 40 Value min: 0 V Airflow max: 220 Value max: 10 V







### **C**·VAV self-sufficient & connected

#### **COMMISSIONING WITH REMOTE CONTROL**


For more information, ask for the dedicated technical documentation of the e-VAV remote control. You will find all the information for modifying the airflow and the other parameters.





#### «Main» Menu

Turn on the remote control, plug the RJ45 and press "Connect e-VAV"










### **C**·VAV self-sufficient & connected

«Connect e·VAV» Menu Select the appropriate menu according to your needs



The remote control allows you to modify all the e-VAV parameters : airflow,  $CO_2$  level, ..... In order to modify parameters, the remote control has to be wirely plug into e-vay.








### **C**·VAV self-sufficient & connected

#### MONITOR YOUR INDOOR AIR QUALITY AND ACT ON YOUR SYSTEM

The e-VAV communicates with LoRaWAN protocol. It allows you to manage all parameters remotely.

With the integrated sensors, you can monitor the indoor air quality (CO<sub>2</sub>), the comfort and all the airflows in your buildings. You can check the damper efficiency, optimize the consumption and the costs.

You can act to change the configuration of the damper remotely controlled through the LoRa network. It allows you to adjust your ventilation system to optimize it during all the building life cycle.



#### Benefits of the LoRa e-VAV:

- Monitor the indoor air quality during the whole lifetime of the building
- Act and control your variable air volume damper remotely
- Detect and solve issues without human intervention

#### Products list:

- e-VAV: self-sufficient variable air volume damper
- Gateways: box to receive and send LoRa information
- Dashboard: a ready-to-roll solution to monitor all the dampers



The **e-VAV** can also interact with other IoTs products in the building as for instance a room CO<sub>2</sub> sensor which has LoRa communication.





